WWA-SS SERIES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

WATER SOURCE ALL IN ONE

WWA-SS-8 (230V /50Hz)











1 Contents

System description
Principle of operation 3
Unit Description 3
Principle of heatpump 4

Control panel
Layout 5
Explanation 5
Functions 6
Symbols 6

General information for the installer
Transport and storage 7
Installation 7
Inspection of the installation 7

Pipe connections
General 8
Pipe connection (collector) 8
Pipe connection (Room water side) 9
Pipe connections (water heater) 9
Pump capacity diagrams, Room water side 10
How to adjust the rate of flow 10
Pump capacity diagrams, collector side 11

Electrical connections
Connect the power cord 12
Wiring of the terminal (mode one) 13
Wiring of the terminal (mode two) 13
Connecting the room temperature sensor 14
Connecting the outside temperature sensor 14
Layout of the PCB 15
1.5mm2 terminal connection 15
Part of wiring diagram 16
2.5mm2 / 6mm2terminal connection 16
Wiring diagram (230v / 50 Hz) 17
Description of the switch board 18

Commissioning and adjusting
Preparations 19
Filling the room water cycle system 19
Inspection 20
Adjust the Water source / Room water cycle pump 20
Readjusting, Room water side 20
Emptying the water heater 20

Control
General Information 21
Menus 22
Main Menu Information 22
Sub-menu Operation 22
Sub-menu Heat Curve 23
Sub-menu Temperature 24
Sub-menu Integral 24
Sub-menu Operating Time 25
Sub-menu Reset 26
Sub-menu Man Test 26
Adjustments to be made regularly 26
Heat Generation-General 26
Adjustment of the CURVE valve 27
Adjustment of ROOM valve 28
Adjustment of Part of the Heat Curve 29
Adjustment the MIN and MAX valve 30
Adjustment of the HEAT STOP valve 31
Graph of recent change in TEMPERATURE 32
Maximum Return Line Temperature 33
Warm or cool water Production 33
Regular checks 34
Check of the Operating Mode 34
Checking the Water Level of the Room system 35
Checking the safety valves 35
In the event of leakage 35
Alarm Messages 36
Terminology and Abbreviations 37

Dealing with malfunctions
Draining, Room water cycle side 38
Draining, water tank 38
Draining, collector side 38
Draining, the chassis 38

Component placement
Component positions 1 39
Component positions 2 40
Component positions 230 V / 50 HZ 41

List of components
List of components 42

Dimensions
Dimensions and setting-out coordinates 43

Accessories
Accessories 44
Enclosed kit 44

Technical specifications
Technical specifications 230 V 45

Principle of operation

WWA-SS series consists of a heat pump, water heater, electrical module, circulation pumps and a control system. WWA-SS series is connected to the collector and heating medium circuits.

The heat source of the WWA-SS series is provided from seawater or ground-water. The titanium heat exchanger is used for collecting the heat of water-source.

The Water-source emits its heat to the refrigerant in the evaporator. It then vaporises and is compressed in the compressor. The refrigerant, the temperature of which has now been raised, is passed to the condenser where it gives off its energy to the heating medium circuit and, if necessary, to the water heater. After the condenser there is a built-in electrical module which cuts in if there is a high demand.



The room water side and the hot water side must be fitted with the necessary safety equipment in accordance with the applicable regulations.

3 System description

Unit Description

In order to get the best results from the climate system WWA-SS series you should read through the section For the System manager in these Installation and Maintenance instructions.

WWA-SS series is a climate system for heating houses and apartment buildings as well as industrial properties. Ground-water and seawater can be used as the heat exchange source.

WWA-SS series is a complete heating installation for heating and hot water.

It is fitted with new design on the market to be developed specifically for heat pumps. A new evaporator enables a new and improved circulation system for the refrigerant. The heat pump has an integrated 150 or 200 litre water tank and an immersion heater. The Tap Water Stratification system improves the efficiency of heat transfer by keeping the water in distinct thermal layers in the water tank.

The unit is fitted with a regulating computer, which is controlled over a graphic display unit.

Heat is distributed throughout the house over a hydronic heating system referred to as low temperature system with a maximal water temperature to radiators (supply line temperature) of 65°C. Most of the heating demand is taken care of by the heat pump (compressor unit), the auxiliary heater being started only when demands exceed available heat pump capacity.

WWA-SS series consists of five main components:

a. Heat Pump Unit
Rotory or Scroll-compressor
Stainless steel heat exchangers
Circulation pumps for Ground-water sytem and heating systems
Valves and safety equipment for refrigerant system, complete with necessary electric components

b. Water Heater /cooler
150 or 200 litre
Lined with copper sheet against corrosion or made of stainless steel
Maintenance free as no anode is used

c. Reversing Valve
Opening or closing the connection to water heater according to operating mode: heating or warm water production

d. Auxiliary Heater
3/6/9 kW electric heating element
Three-step capacity control
Fitted on supply line
Delivers back-up heat in case of great heat demand that exceeds heat pump capacity
Starts automatically, provided operating mode “AUTO” has been selected

e. Regulating Equipment
The regulating system controls heat pump components (compressor, circulation pumps, auxiliary heater and reversing valve). Based on data received from sensors, it starts or stops heat pump operation and determines whether heating or warm water shall be produced. The system consists of:
Control computer with graphic display unit
Temperature sensors (outside air,room, supply line, return line,and Ground-water system)

Principle of heat pump

Room heating (for example)

A heat pump can exploit the energy contained in natural heat sources. Or, to put it differently, the heat pump ”collects” heat energy from the heat source. This makes the heat pump a very environmentally friendly and economically sound alternative for space heating.

a. The ground water cycle sytem absorbs the heat energy of the heat source so that the temperature of the water circulating in the hose is raised a few degrees.

b The ground-water sytem is circulated to the heat pump’s evaporator. Here the heat energy of the ground-water sytem causes the refrigerant, circulating through the evaporator, to boil and turn into a gas – it evaporates.

c The refrigerant, having absorbed heat energy, is circulated to the compressor where pressure and temperature are raised.

d The refrigerant continues to the condenser. When condensing, it releases heat energy to the heat carrier, circulating through the condenser. The temperature of the refrigerant sinks, and it returns to its liquid state.

e The heat energy released is carried by the heating circuit to water heater and radiator or floor heating systems.

f At last the refrigerant is led through the expansion valve, where its pressure is reduced, and then continues to the evaporator The process is restarted.

.

The heat pump has three separate liquid circuits

Water-source sytem circuit – The Water-source system transporting energy from heat source to heat pump.

Refrigerant circuit – circulating inside the heat pump. Through evaporation, compression and condensation it absorbs energy from the ground-water sytem and releases it to the heat carrier. The refrigerant is chlorine-free.

Room-water system circuit – water transporting heat energy to the heating system (radiators/floor coils) and the water heater.



5 Control panel

Layout



Explanation

Control Panel

The control panel of WWA-SS features a graphic display five control buttons .

Beside the control panel you will find the User's Manual, a short description of how to increase and reduce room temperature, and a label with name and phone number of dealer.



Graphic display

Functions

The control computer is operated with the help of a user friendly menu system that is displayed on the control panel. There is a main menu and four sub-menus accessible from the main menu. The menus are described in detail further down.

To be able to select the desired menu and increase or reduce preset values, you will use the five buttons.

- One button pointing upwards marked with a plus
- One button pointing downwards marked with a minus
- One button pointing to the right
- One button pointing to the left
- One button pointing to the Power ON/OFF

Symbols

For you to know at a glance the actual operating mode of the heat pump, one of the following symbols will be shown in the lower part of the display depending on which part of the unit is working:

The heat pump is running.

Warm water is being produced.

The auxiliary heater is activated.
The figure next to the symbol indicates capacity step.

Indicates the status of warm water production. If the symbol is empty, warm water temperature is 44°C.

There is a heating demand.



If the symbol is full, warm water temperature is the start temp. + 4°C.

7 General information for the installer

Transport and storage

The WWA-SS series must be transported and stored upright and dry. The WWA-SS series may however be carefully laid on its back when being moved into a building.





Installation

WWA-SS series is placed on a firm base, preferably a concrete floor or foundation. Install WWA-SS series with its back to an outside wall, ideally in a room where noise does not matter. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem. Any wall that backs on to a bedroom should be fitted with sound insulation. Route pipes so they are not fixed to an internal wall that backs on to a bedroom or living room.

Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person and should be documented. The above applies to closed heating systems. If the heat pump is replaced, the installation must be inspected again.

Pipe connections 8

General

Pipe installation must be carried out in accordance with current norms and directives. The heat pump can operate up to a return temperature of about 58* °C and an outgoing temperature of about 70* °C from the heat pump. The compressor produces up to 65* °C, the rest is obtained using additional heating.

The other heat pumps has a max return temperature of approximately 50 °C and an outgoing max temperature from the heat pump of approximately 60 °C.

Since the WWA,WWB series is not fitted with shut-off valves, these must be fitted outside of the heat pump to make future servicing easier.

During assembly the pipes for the heat medium and water heater and possibly hot water circulation are routed backwards. The distance between WWA-SS series and the wall ought to be 50 mm.

NOTE!

The pipe system needs to be flushed out before the heat pump is connected so that debris cannot damage component parts.

Pipe connections (collector)

Factors to be taken into account when designing the collector layout are geographical position, type of ground water and cover factor of the heat pump.

All collector pipes in heated rooms must be insulated against condensation.

The temperature of the Water-source system must be between -12 °C ---- 10 °C .The default is -12 °C



Pipe connections (Room water side)

Pipe connections for the heat medium side are made at the top. All required safety devices, shut-off valves (as close to the heat pump as possible), and particle filter (supplied) are fitted.

When connecting to a system with thermostats on all radiators, a relief valve must be fitted, or some of the thermostats must be removed to ensure sufficient flow.



SF Particle filter

Pipe connections (water heater)

The heat pump´s water heater must be fitted with the necessary valve equipment.



SF Particle filter

The heat pump should be supplemented with an electric water heater if a bubble pool or other significant consumer of hot water is installed. The valve coupling in COMPACT (electrical water heater) can be divided. The mixing valve stays in COMPACT and the remaining valve coupling can be used for incoming cold water in WWA-SS series.

NOTE!

The venting valve should be set on the top of the heating medium system.

Pump capacity diagrams, Room-water side

WWA-SS-8



WILO RL-25/8

How to adjust the rate of flow

WILO RS-25/8

The pump is adjustable to adjust the flow: 1, 2, or 3.

Pump capacity diagrams, collector side

WWA-SS-8



WILO RS-25/8

How to adjust the rate of flow

WILO RS-25/8

The pump is adjustable to adjust the flow: 1, 2, or 3.

Connect the power cord







(230V / 50 HZ)

NOTE!

Electrical installation and service must be carried out under the supervision of a qualified electrician in accordance with the stipulations in force.

Wiring of the terminal (mode one)



Step1 Step2 Step3

Wiring of the terminal (mode two)



Step1 Step2 Step3

Connecting The Room Temperature Sensor



RT=Room temperature sensor

Connecting The Outside Temperature Sensor



OCT=Outside air temperature sensor

Layout of the PCB



1.5mm2 terminal connection


From PCB / CON4 /1,2
From PCB / CON4 /3,4
From PCB / CON4 /5,6
From PCB / CON4 /7,8
From PCB / CON4 /9,10
From PCB / CON4 /11,12
From PCB / CON4 /13,14
From PCB / CON4 /15,16
From PCB / CON5 /1,2
From PCB / CON5 /3,4
From PCB / CON5 /5,6
From
From PCB / CON5 /7,8
From Fuse 1
From Neutral line common terminal
From
From PCB / OUT8
From Neutral line common terminal
From Fuse 2
From Neutral line common terminal
From
From Fuse 3
From Neutral line common terminal
From
From Fuse 2
From Neutral line common terminal
From
From Fuse 3
From Neutral line common terminal
From
WOT WIT WSOT OCT RT WTT WSIT COMP HP LP CSP GND EHI 3WV N GND 4WV N WSCP N GND WCP N GND WSCP2 N GND WCP2 N GND
From Water Outlet Temperature Sensor
From Water Inlet Temperature Sensor
From Water source Outlet Temperature Sensor
From Outside Air Temperature Sensor
From Room Temperature Sensor
From Water Tank Temperature Sensor
From Groundwater Inlet Temperature Sensor
From Compressor Gas Outlet Temperature Sensor
From High Pressure Pressostat
From Low Pressure Pressostat
From Adjustable pressure switch
From Electrical auxiliary heater Temperature Sensor
From Three-way valve forwaterflow
From Four-way valve forwaterflow
From Water source cycle pump
From Water cycle pump
From Water source cycle pump2
From Water cycle pump2

Part of wiring diagram





2.5mm2 / 6mm2 terminal connection





Wiring Diagram(230V / 50 HZ)



Function

Function of manual switch board:

When test or repair the machine, the compressor, Water source cycle pump and water cycle pump can be force manual startup.

A0 1 : Control the compressor;
AA M : Control the Water source cycle pump;
BA M : Control the water cycle pump.


Connect to compressor contactor (A1)
Connect to Fuse 2
Connect to Fuse 3
Switch board
A0 1
AA M
BA M
Connect to the Air break switch (L) (230V/ 50 HZ)

Initial state

The initial state of the manual switch board are such buttons (A0 , AA , BA), all of them are off.(see the picture).
When the machine is running normally,the switch board must be in initial state.



NOTE!

The manual switch board is use only if the necessary for test or repair. when the machine is running normally,the switch board must be in initial state.

Preparations

Before starting up the system, check that the heating, collector and hot water circuits are full and thoroughly vented. Check the pipe system for leakage.

Filling the room water cycle system

The heating medium system is filled with water until the required pressure is reached and then vented.

1. Check the heating medium system for leakage.
2. Connect the filling pump and return line on the heating system's service connections as shown in figure.
3. Close the valve under the level vessel.
4. Close the valve between the service connections.
5. Open the valves on the service connections.
6. Close the valve of the water tank and heating medium.
7. Start the filling pump, and fill until there is fluid in the return pipe.
8. Maintains the travelling schedule pole of the Three-way valve for waterflow at the middle position.
9. Press the power ON botton on the control panel. and start the heating medium pump.
10. The filling pump and the room water cycle pump are now operational. The fluid should circulate via the container with tap water until it emerges from the return hose without being mixed with air.
11. Stop the filling pump and clean the particle filter.
12. Start the filling pump, open the valve between the service connections.
13. Close the valve on the service connection's return line. Now pressurise the system (to max 3 bar) with the filling pump.
14. Close the valve on the service connection closest to the level vessel.
15. Stop the filling pump.
16. Fill the level vessel with liquid up to around 2/3.
17. Open the valve below the level vessel.
18. Close the Room water cycle pump.
19. Select the auto operating mode using the operating mode button.



AVT	Draining	SF	Particle filter
SÄV	Safety valve	NK	Level vessel

Inspection

Adjust the Water source/ Room water cycle pump

1). Read the water source temperatures on the panel. The defference between these two temperatures should be 2—5°C when the system has come into balance. Adjust the flow with the knob on the water source cycle pump (32). A high difference indicates a low ground water flow. A low difference indicates a high water source flow.

The pump is adjustable to adjust water source flow.

2). Check the flow temperature and the return return temperature on the panel. The difference between these two temperatures, with floating condensing, should be 5 — 10 °C when the house is being heated without additional heat. Adjust the flow with the knob on the room-water cycled pump (34). A high difference could depend on a low room-water flow. A low difference indicates a high room-water flow.

The pump is adjustable to adjust Room-water flow.

NOTE!

The compressor must not be forced to start with periods shorter that 1 start per 15 minutes.

Readjusting, Room water side

Air is initially released from the hot water and venting may be necessary. If bubbling sounds can be heard from the heat pump, the entire system requires further venting. When the system has stabilised (correct pressure and all the air removed) the heating controls can be set at the required values.



Emptying the water heater

The siphon principle is used to empty the water heater. This can be done either via the drain valve on the incoming cold water pipe or by inserting a hose into the cold water connection.

General information

Menu Navigation

The right-hand button on the control panel is used to open the desired menu. The left-hand button is used to return to the previous menu. The up and down buttons are used to navigate between the parameters of a menu. A cursor (arrow) on the left-hand side of the display indicates which menu can be opened. The up and down buttons are also used if you wish to increase or reduce a preset value.

Display of current operating mode

During normal operation, the following information will be displayed:

- Desired (preset) room temperature
- Whether there is a heating demand or not. If there is, there will also be symbols telling which heat source is working– heat pump or auxiliary heater or both (see "Symbols" on page 6).



- Which operating mode has been selected In addition to this, the following messages may be displayed:
- PHASE SEQUENCE
  The compressor in the heat pump is running in the wrong direction, which means that heat is produced by the auxiliary heater only (see "Alarm" on page 36).
- HIGH RETURN (for room heating)
  The temperature of the water returning from the radiators is too high so the heat pump will not be allowed to produce heat. (see "Alarm" on p. 36).
- LOW RETURN (for room cooling)
  The temperature of the water returning from the radiators is lower than 5 °C , so the heat pump will be stopped. (see "Alarm" on p. 36).
- START
  The heat pump is in the processs of starting. There is a 30 second delay bet-ween start of Ground water sytem pump and compressor.
- START_MIN
  The heat pump will start in the number of minutes indicated in the display.

Menus

Main Menu INFORMATION

To open the main menu INFORMATION, press the right- or left-hand button once.



To select the desired sub-menu use the up or down button.

Open the menu by pressing the right-hand button once.

To return to the main menu, press the left-hand button once.

Sub-Menu OPERATION



This menu is used for the selection of operating mode. The control system allows for five different operating modes:

- OPERATION HEAT PUMP ON
  Heat pump (compressor) operation is allowed by the control system.
- OPERATION HEAT PUMP OFF
  Heat pump (compressor) operation is not allowed by the control system.
- OPERATION ADD.HEAT ON/OFF
  The auxiliary heater will/will not be allowed to operate. This operating mode is normally used when a new installation is being put into service, before the Water system is ready for use.
- OPERATION ROOMCOOL (Choose ROOMAIR First)
  The heat pump will be distributed to the cooling system only; The heat pump will not produce cool water. The text"OPERATION COOL" will be displayed on the control panel.
  ROOMCOOLING and COOLWATER PRODUCING can be run at the same time.
- OPERATION ROOMHEAT (Choose ROOMAIR First)
  The heat pump will be distributed to the heating system only; The heat pump will not produce warm water. The text"OPERATION HEAT" will be displayed on the control panel.
  ROOMHEATING and WARMWATER PRODUCING can be run at the same time.
- OPERATION WARM/COOL WATER
  The heat pump will only produce warm/coolwater; no heat will be distributed to the heating system. The text"OPERATION WARMWATER "will be displayed on the control panel.

Menus

- OPERATION OFF

  Heat pump is turned off. The following text is displayed on the control panel: “OPERATION OFF“

  If the heat pump will be put in OPERATION OFF mode during winter, please remember to let out all the water the heating system to avoid any damage caused by freezing.

If you wish to change operating mode:

a. Open the main menu INFORMATION by pressing the right-hand button once. You will find the sub-menu named OPERATION.

b. Open the OPERATION menu by pressing the right-hand button once.

c. Select the desired mode by pressing either the ”up” or ”down” button.

d. Return to the main menu by pressing the ”up” button until to the top,and press left-hand button twice.

Sub-Menu HEAT CURVE

This menu is used for making adjustments that affect the room temperature.For more information, please refer to ”Adjustments to be made regularly” on page 26.



Table 1: Menu– HEAT CURVE

Menu Text	Description	Adjustable by:
CURVE	The value entered shows the temperature of the water to be distributed to the radiators(supply line temperature) when the outside air temperature is 0°C.	User (see”Adjustment of CURVE value” on p. 27)
MIN	Adjustment of value for lowest supply line temperature allowed.	User (see ”Adjustment of MIN and MAX values” on p. 30)
MAX	Adjustment of value for highest supply line temperature allowed.	User (see ”Adjustment of MIN and MAX values” on p. 30)
CURVE 5	Adjustment of room temperature when the outside air temperature is +5°C.	User (see ”Adjustment of CURVE value” on p. 27)
CURVE 0	Adjustment of room temperature when the outside air temperature is 0°C.	User (see ”Adjustment of CURVE value” on p. 27)
CURVE – 5	Adjustment of room temperature when the outside air temperature is -5°C.	User (see ”Adjustment of CURVE value” on p. 27)
HEAT STOP	Production of radiator heat is stopped when outside air temperature is equal to or higher than the value for heat stop entered	User, if require

Menus

Sub-Menu TEMPERATURE

This menu shows the different temperatures of the heating system. All temperature changes registered over the last 60 minutes are stored in the control system and can be viewed in the shape of graphs.

NOTICE:

When the "ROOMCOOL" is running , the temperature of the room-water flow (feed line) can be adjusted between 8°C and 28°C.



Table 2: Menu TEMPERATURE

Menu Text	Description	Adjustable by:
OUT	Outside air temperature	-------
ROOM	Desired (setpoint) room temperature	User (see "Adjustment of ROOM value" on page 28).
FEED	Actual (measured) supply line temperapture of heating system; in brackets the setpoint (desired) value.	Not adjustable. (The temperature necessary to keep the desired room temperature is determined by the control system).
RETURN	Measured return line temperature of heating system; in brackets the maximum return temperature allowed.	Installation contractor.To be adapted to each individual unit
WARMWT	Measured warm water temperature; in brackets the starting temperature for warm water production.	Not adjustable.
WATER IN	Temperature of water source sytem when entering the heat pump.	Not adjustable.
WATER OUT	Temperature of water source sytem when leaving the heat pump.	Not adjustable.

Sub-Menu INTEGRAL



Menus

Menu Text	Description	Adjustable by:
OFF	When the value (testing) reaches the value setting by user, the system will be closed.	USER
CMP.A	When the value (testing) reaches the value setting by user, the compressor will be start-up.And the value(testing) under the value(setting),the compressor will be closed.	USER
ADD1	When the value (testing) reaches the value setting by user, the ADD1 will be start-up.And the value(testing) under the value(setting),the ADD1 will be closed.	USER
ADD2	When the value (testing) reaches the value setting by user, the ADD2 will be start-up.And the value(testing) under the value(setting),the ADD2 will be closed.	USER
ADD3	When the value (testing) reaches the value setting by user, the ADD3 will be start-up.And the value(testing) under the value(setting),the ADD3 will be closed.	USER

Sub-Menu OPERATING TIME



Table 3: Menu OPERATING TIME

Menu Text	Description	Adjustable by:
HEATPUMP	Total operating hours of heat pump since installation. Operating time will not be reset to zero.	USER
ADD 1	Total operating hours of auxiliary heater (3kW) since installation. Operating time will not be reset to zero.	USER
ADD 2	Total operating hours of auxiliary heater (6kW) since installation. Operating time will not be reset to zero.	USER
ADD 3	Total operating hours of auxiliary heater (9kW) since installation. Operating time will not be reset to zero.	USER
WARMWT	Total operating hours of water heater since installation. Operating time will not be reset to zero.	USER

Menus

Sub-Menu RESET

Reset to factory setting value.

Sub-MenuMAN TEST



How to enter the Sub-Menu MAN TEST:

You need to choose the 'MAN TEST"on the main menu (INFORMATION)
And press the right button for 3 second .

The Sub-Menu MAN TEST contains ADD1 / ADD2 / ADD3 / HEAT PUMP / 3 WAY / WATER SOURCE PUMP / ROOM WATER PUMP ; You can choose ON / OFF to control the each part for testing.

Adjustments to be made regularly

Most settings will be made by the installation contractor in connection with installation. Adjustments to be made regularly by the user are the following:

- Selection of operating mode
- Adjustment of desired room temperature by changing the ROOM value.
- Adjustment of heat curve
- Adjustment of maximum and minimum values for supply line temperature

Adjustment of the value for HEAT STOP is possible. (Please refer to ”Adjustment of HEAT STOP value” on p. 31).

Heat Generation-General

The indoor temperature should be adjusted by changing the heat curve of the installation. The control computer determines the correcttemperatur e of the water to be distributed to theheating system based on the heat curve.

The heat curve will be adjusted in connection with installation. It must be adapted later on, however, to obtain a pleasant indoor temperature under any weather condition. A correct heat curve reduces maintenance and saves energy.

The heat curve determines the supply line temperature depending on the outside air temperature. The lower the outside air temperature, the higher the supply line temperature. In other words, the temperature of the water fed to the radiators will increase exponentially as the outside air temperature falls.

If you select CURVE in the sub-menu named HEAT CURVE, a diagram will be displayed. It represents the relation of outside air temperature to supply line temperature. This relation is referred to as heat curve.

Adjustments to be made regularly



Adjustment of the CURVE value

The heat curve will be adjusted by the CURVE value. This value indicates the supply line temperature to the radiators at 0°C outside temperature. At outside air tempe-ratures lower than 0°C, the water sent to the radiators will be warmer than 40°C.
At outside temperatures higher than 0°C, the water will be colder than 40°C. When you increase the CURVE value, the heat curve will become steeper and when you reduce it, it will become flatter.

This is the most energy and cost efficient way to set the indoor temperature and should therefore be used for long term temperature settings. If you wish to make a temporary change of temperature, you can simply change the ROOM value (see "Adjustment of the ROOM value" on page 28).
Factory setting of CURVE value is 40°C, at an outside air temperature of 0°C. The value is adjustable between 22°C and 56°C



Change of value for CURVE

If you wish to change the CURVE value:

1 Open the main menu INFORMATION by pressing the right- or the left-hand button once.
You will find the cursor at the sub-menu named OPERATION
2 Press the "down" button to move the cursor to the sub-menu called HEAT CURVE.
3 Press the right-hand button once to open the menu. You will find the cursor at the parameter CURVE
4 Open the selected parameter by pressing the right-hand button once.
5 Increase or reduce the preset value using the "up" or "down" button. You will see from the diagram how the gradient of CURVE changes.

Press the left-hand button three times to return to the main menu.

Adjustments to be made regularly

Adjustment of ROOM value

As mentioned above, you can also adjust heat curve and indoor temperature by changing the ROOM value. If you use ROOM value to adjust the heat curve, the gradient does not change, i.e. it doesn't become steeper or flatter. Instead, the whole curve is moved by 3°C for every degree by which the ROOM value is changed.

The relation supply line temperature to outside air temperature will not be affected. The supply line temperature will be increased or reduced by the same number of degrees all along the heat curve. See the following diagram.

Adjustment of the ROOM value should only be used for temporary changes of the indoor temperature. For long term settings, the CURVE value should be adjusted as this is the most energy and cost efficient way to set the indoor temperature.

For adjusting the heat curve, please refer to the chapter "Adjustment of the CURVE value" on page 27.

Factory setting of ROOM value is 20°C.



Changing the ROOM value

If you wish to change the ROOM value:

1 Press the "up" or "down" button once to open the ROOM value for adjustment.

2 Increase or reduce the preset value using the "up" or "down" button so that the desired room temperature is reached. Wait for 10 seconds or press the left-hand button once to return to the main menu.

Adjustments to be made regularly

Adjustment of Part of the Heat Curve

At outdoor temperatures between -5°C and +5°C part of the heat curve may need adjusting if the indoor temperature does not stay at the preset ROOM value. For this reason, the control system includes a function adjusting the curve at three outside temperatures: -5°C, 0°C, +5°C. This function will allow you to increase or reduce the supply line temperature, without affecting the heat curve, at three specific outdoor temperatures. If, for example, the outside temperature is -5°C,the supply line temperature will change gradually in the outdoor temperature range of 0°C to -10°C, maximum adjustment being reached at -5°C. The diagram below shows an adjusted CURVE-5. The point of maximum adjustment is clearly visible.

As we have seen, you can choose to adjust the heat curve at three specified outside air temperatures: -5°C, 0°C and +5°C. The supply line temperature can be changed by plus/minus 5 degrees.



Change of the value for CURVE -5

If you wish to change a specific part of the heat curve:

1 Open the main menu INFORMATION by pressing the right- or left-hand button once.You will find the cursor at the sub-menu OPERATION.

2 Press the ”down” button to move the cursor to the sub-menu HEAT CURVE.

3 Open the selected menu by pressing the right-hand button once. You will find the cursor at the parameter CURVE.

4 Using the ”up” or ”down” button, select either CURVE 5, CURVE 0 or CURVE -5.

5 Open the selected curve by pressing the right-hand button once.

6 Raise or lower the value, using respectively the ”up” or ”down” button. To return to the main menu, press the left-hand button three times.

Adjustments to be made regularly

Adjustment of the MIN and MAX value

The MIN and MAX value is the lowest respectively highest value that is allowed for the supply line temperature. Adjusting the minimum and maximum supply line temperature is particularly important if your home has floor heating.If your house has floor heating and parquet floor, the supply line temperature should not be higher than 45°C. Else the floor might get damaged. If you have floor coils and stone tiles, the MIN value should be 22-25°C in summer when no heating is required – to obtain a comfortable floor temperature.

If there is a basement to your house, the MIN value should be adjusted to a suitable temperature in summer too, to avoid a humid and chilly basement. In such cases,the value for HEAT STOP needs being adjusted upwards.

If you wish to change the MIN or MAX value:

1 Open the main menu INFORMATION by pressing the right- or left-hand button once. You will find the cursor at the sub-menu OPERATION

2 Press the ”down” button to move the cursor to the sub-menu HEAT CURVE

3 Open the selected menu by pressing the right-hand button once. You will find the cursor at the parameter CURVE.

4 Press the ”down” button to move the cursor to MIN.

5 Open the selected parameter by pressing the right-hand button once. The cursor is at MIN

6 Raise or lower the value, using the ”up” and ”down” button respectively.

7 Press the left-hand button three times to return to the main menu.

Repeat the procedure to change the MAX value, replacing MIN by MAX at step 4.

Adjustments to be made regularly

Adjustment of the HEAT STOP value

The HEAT STOP function stops all production av radiator heat when the outside air temperature is equal to or higher than the value entered for heat stop.When the heat stop function is activated, the circulation pump will be turned off except when warm water is being produced. Even if shut off, the pump will be”exercised” during 1 minute a day. Factory setting for heat stop is 17°C.

If you wish to change the HEAT STOP value:

1 Open the main menu INFORMATION by pressing the right- or left-hand button once.
You will find the cursor at the sub-menu OPERATION

2 Press the ”down” button to move the cursor to the sub-menu HEAT CURVE

3 Open the selected menu by pressing the right-hand button once.

4 You will find the cursor at the parameter CURVE.

5 Press the ”down” button to move the cursor to HEAT STOP

6 Open the selected parameter by pressing the right-hand button once. The cursor moves to HEAT STOP

7 Raise or lower the value, using respectively the ”up” or ”down” button.

8 Press the left-hand button three times to return to the main menu.

Adjustments to be made regularly

Graph of recent changes in TEMPERATURE

All temperatures registered during the last hour can be viewed in the sub-menu TEMPERATURE in the shape of a graph. This will enable you to monitor changes in the different system temperatures.



There is a graph available for all temperatures, except for the ROOM temperature,where you can only view the setpoint value. The integral value that is displayed represents the heating system's energy balance.

If you wish to check the TEMPERATURE graphs:

1 Open the main menu INFORMATION by pressing the right- or left-hand button once.
You will find the cursor at the sub-menu OPERATION.

2 Press the "down" button to move the cursor to the sub-menu TEMPERATURE

3 Open the menu by pressing the right-hand button once.

4 You will find the cursor at the parameter OUT.

5 Press the "down" or "up" button to move the cursor to the desired temperature.

6 Open the selected value by pressing the right-hand button once. A graph will be shown in the display.

7 Move the cursor along the time axis using the "up" (plus) or the "down" (minus) button.
The exact temperature at the selected point of time appears at the top of the display.

8 Press the left-hand button three times to return to the main menu.

Maximum Return Line Temperature

The maximum return line temperature, i.e. temperature of the water returning from the heating system, should be adapted to each individual installation. The correct temperature value for your system will be entered by your installation contractor in connection with installation and can be adjusted later.

Warm or Cool Water Production

The temperature of the water distributed to the water heater is controlled by the regulating pressure switch and cannot be adjusted.

Reading of warm water temperature.

To check the actual warm water temperature on the display:

1 Open the main menu INFORMATION by pressing the right- or left-hand button once. You will find the cursor at the sub-menu OPERATION.

2 Press the ”down” button to move the cursor to the sub-menu called TEMPERATURE.

3 Open the menu by pressing the right-hand button once.

4 Press the ”down” button to move the cursor to the parameter WARMWATER.

5 Open the selected parameter by pressing the right-hand button once.

A graph will be shown of last hour’s warm water temperatures.

6 Press the left-hand button three times to return to the main menu.

The value displayed next to the parameter WARMWATER is the actual hot water temperature. The value in brackets is the temperature at which warm water production will start. When the actual temperature falls below that value, warm water production starts. The starting value is not adjustable.

Regular Checks

Check of Operating Mode

In the event of an alarm, The background light of LCD will flash and an alarm message will be displayed.

Check the alarm indicator regularly to make sure that the heat pump works properly. You would not always notice if there is something wrong, as the auxiliary heater would start automatically (provided, of course, operating mode AUTO was selected). For more information, please refer to the chapter ALARM MESSAGES on p. 36.

Checking the Water Level of the Room water System

The pressure of the Room water system should be checked once monthly. The pressure, shown on the external pressure gauge, should be 1-1,5 bar. If the value is below 0.8 bar with cold water in the system, more water must be added (applies to a closed expansion vessel). To find out where the pressure gauge is located.

You can use ordinary tap water for filling the Room water system. In some rare cases the water quality would be unsuitable for this purpose (corrosive or calcareous water). In case of doubt, we would recommend that you call your installation contractor.

Don’t use any water treatment additives for the Room water system!



Level is too low **Level is correct**

Regular Checks

Checking the Safety Valves

Both safety valves of the heating system should be checked at least four times a year to prevent lime deposits to clog the mechanism. To find out where the safety valves are located.

The safety valve of the water heater protects the closed heater against positive pressure. It is fitted on the cold water inlet line, its outlet opening facing down- wards. If the safety valve is not checked regularly, the water heater might be damaged. It is quite normal that the safety valve lets out small amounts of water when the water heater is being charged, especially if a lot of warm water was used previously.

To check the safety valves, give the cap a quarter of a turn clockwise until the valve lets out some water through the overflow pipe.

If a safety valve does not work properly, it must be replaced. Check with your installation contractor.

The opening pressure of the safety valve is not adjustable.

In the Event of Leakage

In the event of leakage in the warm water lines between unit and water taps, the shut-off valve on the cold water inlet line should be closed immediately.
Call your installation contractor. In the event of leakage in the Brine system circuit, turn off the heat pump and call your installation contractor immediately.

Alarm Messages

In the event of an alarm message, try to re-start the unit with the safety switch.

If this does not work, try to solve the problem with the help of the table below. Call your installation contractor if you need help.

Table : Alarm Messages

Message	Signification	Cause	Action
LOW PRESS ERROR	Low pressure switch cut out. Compressor is stop- ped. No warm water is produced.	Not enough liquid in Ground water system. Air in Ground water system. Clogged strainer in Ground water system	Call your installation contractor.
HIGH PRESS ERROR	Low pressure switch cut out. Compressor is stop- ped. No warm water is produced.	Not correctly opened radia- tor/ floor coil thermostats. Air in heating system. Clogged strainer in heating system.	Open radiator or floor coil thermostats. Fill and bleed the heating system or call the installation contractor.
MOTOR P ERROR	Motor protection cut out. Compressor is stopped. No warm water is produced.	Power failure caused by fuse or safety switch.	Open radiator or floor coil thermostats. Fill and bleed the heating system or call the installation contractor.
ADD ERROR	Overheat protection cut-out.	Electrical fault. The safety switch has cut out.	Check fuses and reset safety switch if cut out.
OUT SENSOR	Error outside air sensor. The value 0°C will be used for calculation of supply line setpoint value.	Electrical fault	Call your installation contractor.
FEEDLINE SENSOR	Error supply line sensor. All operation stopped, except circulation pump of heating system.	Electrical fault	Call your installation contractor.
RETURN SENSOR	Error return line sensor	Electrical fault	Call your installation contractor.
WARM WATER	Error warm water sensor. No warm water production.	Electrical fault.	Call your installation contractor.
ROOM SENSOR	Actual (measured) room temperature is not displayed. The value 20°C will be used for calculation of supply line setpoint temperature.	Electrical fault.	Call your installation contractor.
ERR PHASE SEQ	Heat pump compressor rotates in the wrong direc- tion. Heat is produced by auxiliary heater only.	Phase order reversed when changes were made to electric installation.	Call your installation contractor
HIGH RETURN	Temperature of water returned from radiators too high. Heat pump operation is not allowed. .	Not correctly opened radiator/ floor coil thermostats	Make sure that all thermostats are completely open
lARGE DIFFERENCE IN TEMPERATURE	Temperature of return line higher than temperature of supply line 13°C . Heat pump.will be stopped.	Not correctly opened radiator/ floor coil thermostats	Call your installation contractor
LOW RETURN	Temperature of water returned from radiators lower than 5°C . Heat pump will be stopped.	Not correctly opened radiator/ floor coil thermostats	Make sure that all thermostats are completely open

Message	Signification	Cause	Action
WATER SOURCE OUT	Temperature of Water source leaving heat pump is lower than setpoint value. Compressor is stopped and no warm water is produced.	The minimum Water source sytem temperature has been reached	The system resets automatically when temp. has risen to setpoint value
WATER SOURCE FLOW LOW	Flow switch not active at latest compressor start. Compressor is stopped and no warm water is produced.	Water source sytem flow is too low.	Call installation contractor

Terminology and Abbreviations

Evaporate	In the evaporator, energy from the heat source is absorbed by the refrigerant passing through the evaporator. The refrigerant turns into gas. (See "Heat Pump Principle" on p. 4).
INTEGRAL	INTEGRAL is the heat balance of the heating system. Production of heat is regulated acc. to a calculated heat demand value. This value is determined by comparing the actual supply line temperature with its calculated (setpoint) value. The difference between the two values is multiplied by the time during which the difference is active. The resul-ting value is referred to as the integral. The integral value is automatically established when heat is being produced. The value can be viewed in the sub-menu TEMPERATURE.
Compressor	The compressor raises temperature and pressure of the the refrigerant (See "Heat Pump Principle" on p.4).
Condenser	In the condenser ,the r efrigerantreleases its heat ener gyto the heatingcircuit. (See"Heat Pump Principle" on p.4)
CURVE	The CURVE value will be adjusted on the control panel. The value indicates the temperature of the water distributed to the radiators (supply line temperautre) at an outside air temperature of 0°C.
Refrigerant	Circuit in the heat pump filled with refrigerant that by evapo-ration, compression, and circuit condensation absorbs heat energy from the Water- source sytem circuit and releases it to the Heating circuit.
Refrigerant	Liquid absorbing energy from the Water-source sytem circuit and releasing it to the heating circuit. (See "Heat Pump Principle" on p. 4).
Radiator	Heating element
Control	The control computer regulates the whole installation. All system settings and computer temperature changes are stored and registered in the computer. Settings are adjusted via the graphic display on the control panel.
Heating circuit	The heating circuit receives heat energy from the refrigerant circuit and carries it to the water heater or radiator/ floor coil systems. (See further"Heat Pump Principle" on p.4).
Heat curve	The heat curve is the control computer's instrument for determining the required supply line temperature of the heating system. Indoor temperature will be adjusted by adjustment of the CURVE value

Draining, Room water side

Close the shut-off valves in Room water system. Open the drain valve (77),(79). A small amount of water runs out, however, to fully empty the Room water side requires the connector that joins the Room water side and the connection on the heat pump to be loosened a little to allow air to enter so the remaining water can run out. When the Room water is empty the requisite service can be carried out.



Draining, water tank

First,close the drain valve (77),(78).And then open the drain valve (76). When the water tank is empty the requisite service can be carried out.

Draining, collector side

When replacing the Water source cycled pump or drive side or when cleaning the pump the collector side should be drained.
First,close the drain valve (77),(78).And then open the drain valve (76),(79). When the water tank is empty the requisite service can be carried out.



Draining, the chassis

The drain-pipe for the chassis is already assembled in advance before leaving the factory. The consumer is required to place the hose at appropriate location.



If the operating disturbance cannot be rectified by means of the above, an installation engineer should be called.

Component placement








27
28
29
26


18
24
25
23
22
17
20
19
21


69
71
73
68
59
67
60
61
72
62
66
63
64
65
70


52
53
42
43
44
30
57
54
55
31
49
34
32
33
50
35
46
37
45
38
51
58
47
56
48


40
41
36
33
39

230 V /50 HZ





1 Top board
2 Right side board
3 Left side board
4 Glass upper door
5 Glass lower door
6 Front board
7 Board for fixing control panel
8 Collector,water source out
9 Collector,water source in
10 Stainless steel adjustable feet
11 Control panel
12 Control panel Box
13 Connecting wire of control panel
14 Door lock
15 Chassis
16 Sound insulation board
17 Connection,room water return Ø 28 mm
18 Level vessel,connection /1 inch
19 Connection,room water flow Ø 28 mm
20 Water inlet
21 Water outlet
22 Power cord connection hole
23 Temperature sensor connection hole
24 Room temperature Sensor connection
25 Outside air temperature sensor connection
26 Water tank
27 wire groove
28 Temperature sensor (Water Tank)
29 Three-way valve for waterflow
30 Electrical Auxiliary heater
31 Stainless steel plate heat exchanger
32 Water source cycle pump
33 Compressor
34 Room water cycle pump
35 Expansion valve
36 Titanium heat exchanger
37 Adjustable pressure switch
38 Drying filter
39 Oil tank
40 High pressure pressostat
41 Valve
42 Four way valve
43 Low pressure pressostat
44 Pinhole valve
45 Water source inlet pipe
46 Water source outlet pipe
47 Water source inlet connection
48 Water source outlet connection
49 Room water return pipe
50 Room water flow pipe
51 Waterspout
52 Temperature sensor (Electrical auxiliary heater)
53 Temperature sensor (Compressor gas outlet)
54 Temperature sensor (Room water return)
55 Temperature sensor (Water source inlet)
56 Temperature sensor (Room water flow)
57 Drainpipe for Water tank
58 Temperature sensor (Water source outlet)
59 Transformer
60 Neutral line common terminal
61 Circuit board
62 AC contactor
63 Capacitor
64 1.5mm^{2}terminal
65 2.5mm^{2}terminal
66 6mm^2 terminal 1
67 Switch board
68 Air break switch cover
69 Fuse 1 for 3 way valve
70 Fuse 2 for Water source cycle pump
71 Fuse 3 for Room water cycle pump
72 Fuse 4 for Electrical heater 1
73 Fuse 5 for Electrical heater 2
74 6mm^2 terminal 2
75 Air break switch
76 Draining valve for water tank
77 Draining valve for room water
78 Draining valve for Titanium heat exchanger
79 Draining valve for room water pump
80 Draining hole
81 Room temperature sensor
82 Ourside air temperature sensor
83 Connecting ground water with insulation
84 conex connectors
85 Particle filters
86 Draining pipe for the chassis
87 draining connector
88 Level vessel
89 Adjustable three-way valve for waterflow

Dimensions and setting-out coordinates





Enclosed kit







Technical specifications 230 V

CE IP 21

Type		8
(Heating)Delivered/Supplied power* at 0/35 °C ** (KW)		7.8/1.87
(Heating)Delivered/Supplied power * at 0/50 °C ** (KW)		7.0/2.30
(Cooling)Delivered/Supplied power* at 35/7 °C ** (KW)		7.7/2.75
(Cooling)Delivered/Supplied power * at 43/7 °C ** (KW)		6.8/3.38
Operational voltage	(V)	230 V / 50 HZ
Starting current, compressor	(A)	24
Max operational current, compressor	(A)	16
Max operating curr. incl. immersion heater 6 kW	(A)	27
Output, Water source cycle pump	(W)	151
Output, Room water cycle pump	(W)	151
Connection water source o.d. ø	(mm)	28
Connection room water cycle, o.d. ø	(mm)	28
Water tank inlet/outlet, o.d. ø	(inch)	1/2''
Required ceiling height	(mm)	1980
Volume, water heater/cooler	(litres)	150
Volume, spiral copper pipe	(litres)	7.3
Max pressure in storage heater	(MPa)	0.9 (9 bar)
Max pressure in spiral copper pipe	(MPa)	0.25 (2.5 bar)
Refrigerant quantity (R407C)	(kg)	1.00
Water source flow	(l/s)	0.55
Max pressure collector system	(bar)	3
Operating temperature collector system	(°C)	-12 +20
Room water flow	(l/s)	0.41
Max temp. (flow/return circuit)	(°C)	68/55
Difference pressostat HP	(bar)	-7
Cut-out value pressostat HP	(bar)	28
Difference pressostat LP	(bar)	+1,5
Cut-out value pressostat LP	(bar)	0.5

* Compressor output only.
** Refers to the ground water flow temperature/Room water flow temperature in accordance with EN 255.
*** With feet and connections dismantled the height is 1900 mm.
**** The compressor produces up to 65 °C, the rest is obtained using additional heating.